









YEALINK TOUCH SCREEN (T57W) QUICK START GUIDE

You can do more than make or take calls with your new phone.
But first, you'll need to connect it to your Wi-Fi.

Follow these simple steps and you'll be fully operational in just a few minutes.



1. Select **Menu > Basic > Wi-Fi** and press the **On** radio button




2. Scroll to **Available Networks**

3. Select your Wi-Fi network and use virtual keyboard to enter password

4. Collapse virtual keyboard

5. Select **OK**

6. The selected network will now appear with a **'Connect Successfully!'** message in the list of **Available Networks**



7. Press **Home** to return to the main screen

